


CSBL-1000 IO控制板(鋼印板)

2012/6/11

8	7	6	5	4	3	2	1
IN4	+24V	GND	IN2	+24V	GND	IN0	+24V
15	14	13	12	11	10	9	
GND	IN3	+24V	GND	IN1	+24V	GND	

1	2	3	4	5	6	7	8
HOFF	PLS	DIR	EP0	EP1	EP2	EP3	
9	10	11	12	13	14	15	
+24V	+24V	+24V	+24V	+24V	+24V	+24V	+24V



24V輸出

24V輸出

8	7	6	5	4	3	2	1
GND	IN11	IN10	IN9	IN8	IN7	IN6	IN5
15	14	13	12	11	10	9	
+24V	P6-	P6+	P5-	P5+	P4-	P4+	

無帶電光耦合接點